


Block diagram



Commissioning

Commissioning with web server

Use the web server integrated in the converter for the commissioning. The Web server integrated in the converter supports the following browsers:

- Microsoft Internet Explorer 11
- Microsoft Edge ≥ V14
- Mozilla Firefox ≥ 48
- Google Chrome ≥ V52

Preparation for commissioning

- Mount the motor on the mechanical system. Connect the motor to the converter.
- Connect the converter to your Commissioning-PC via the Ethernet interface (X127).
- Switch the converter on.

The converter powers up and reads the motor data.

- Start the Internet-Browser for commissioning.
- Enter the IP address of the converter in the input line of your browser.

Default-IP-Address: 169.254.11.22 (Subnet-Mask: 255.255.0.0).

Note

If the RDY LED is blinking fast in yellow after the first power up of the converter, then a power cycle is required after an update of a motor component. Turn the 24V supply of the converter off and back on again.

Assigning an Administrator password

In order to get full access to the converter you have to log-in as Administrator.


For the access as Administrator a password is required.

After powering up the converter a dialog to enter the Administrator password appears for 10 min. The following mask appears only if the Administrator password has not been assigned and only for the duration of 10 minutes after powering up the converter.

Assign an Administrator password.

Note

Note down the password and store it carefully in a secure place!




Login

After assigning the Administrator password the Log-in page is displayed.

Enter the login „Administrator“ and the password which you have assigned in the step before.

After a successful log-in the Overview page appears.

Overview of web server



- ① Button: Save retentively (Copy RAM to ROM)
- ② Button: Support information
- ③ Button: Call control panel
- ④ Active view of the Web server (in the example: View after user login)
- ⑤ Navigation toolbar (see following "Navigation of the Web server")
- ⑥ Icon: Start page
- ⑦ Message display of the converter: Displays the status of the converter and active faults and alarms
- ⑧ Line with general information
- ⑨ Drop-down list for the language selection and to log out from the Web server.

For more detailed information, please refer to the S210 Operating Instructions.

WARNING


Danger due to moving parts of the machine

During the following steps the motor will rotate. Please make sure that the motor is mounted and connected correctly and that the connected mechanics may be moved without causing a damage or injury.

Perform a One-Button-Tuning

For the optimization of the control parameters, perform the following procedure:

- Select 'Commissioning'
- Select 'Tuning'
- Click on „Take Control“ and confirm the confirmation prompt (Orange/white bar appears).
- Choose a Dynamic setting according to the mechanical capabilities of your machine.
- Click on „Start tuning“.
- Enter the permissible angle of rotation for the required measurement about which the motor and the connected machine are permitted to turn without causing a damage to the mechanics (the angle should at least be 60°, a greater angle leads to better results).
- Confirm with OK and the tuning will start.



Control panel

It is required to move the axis this can be done using the control panel. Click on the button 'Control panel' in the footer, take over the control and enter the desired speed. Now the axis can be moved by holding the 'Rotate Left/Right' buttons.

Additional functions

Further adjustments can be made by selecting the menu item 'Parameters'.


You can also save the parameter settings and restore them later if required or you can reset the converter to the factory defaults. For this choose the menu item 'Backup & Restore'. In the 'System' menu you can change passwords and enable the access to the web server via the Profinet interface (X150).

Saving changes

In order to save the changes permanently click on the floppy disk symbol in the footer.

Messages

In the menu choose 'Diagnostics' and 'Messages' to display the Warnings and Alarms including information concerning cause and remedy. A detailed description of the events is available in the manual.



Diagnostics

Diagnostic of the converter

Besides the diagnosis with the Webserver troubleshooting can be done directly on the device. The alarms and faults are shown in the display of the converter according to the message classes defined in PROFIdrive.



Display and operational elements

The converter displays the current operating state via two LEDs.

- RDY: Status of the converter
- COM: Status of the communication

Faults can be acknowledged with the OK button.

When using an SD-Card, push it into the slot (label to the left). When parameters were saved on the card after commissioning, an easy exchange of the converter is possible in case of a defect. Switch the converter off to plug-in or remove the SD card.

Message number	Description
1	Hardware/software error Hardware or software malfunction
2	Network fault A line supply fault has occurred (phase failure, voltage level, etc.)
3	Supply voltage fault Power supply fault (24 V) has been identified
4	DC link overvoltage The DC-link voltage is too high
5	Power electronics fault Failure in power electronics (overcurrent, overtemperature, IGBT failure,...)
6	Overtemperature electronic component Temperature of electronics exceeded the highest permissible limit
7	Ground fault / inter-phase short-circuit detected Failure in the power cables or motor windings
8	Motor overload The motor has exceeded its limits
9	Communication error to PLC Interrupted or failed network communications
10	Safety monitoring channel detected an error A safe operation function has detected an error
11	Position actual value/speed value error Encoder signal error detected (track signals, zero marks, absolute values...)
12	Internal (DRIVE-CLiQ) communication error Communications between SINAMICS components is faulty or has been interrupted
13	Fault infeed The infeed is faulty or has failed.
14	Braking controller / Braking Module error Braking Module fault or overloaded
15	Line filter fault The line filter exceeded temperature limits or has non-permissible state
16	External value/signal out of the range Digital/Analog inputs error (or temperature)
17	Application / technology fault Application or technology function has exceeded a limit (position, velocity, torque...)
18	Error in the configuration/commissioning Error in the commissioning procedure, or the configuration of the device
19	General drive fault Group fault
20	Auxiliary unit fault Auxiliary unit has identified an illegal state.

Safety functions

A detailed description of the Safety commissioning can be found in the S210 operation instructions under www.siemens.com/sinamics-s210

Correcting faults of the motor

Fault	Cause of fault (see 'Fault cases and remedial measures' below)		
Motor does not start	A	B	
Motor starts slowly	A	C	F
Humming sound when starting		C	F
Humming sound in operation	A	C	F
High temperature rise under no-load operation		D	I
High temperature rise under load	A	C	I
High temperature rise of individual winding sections			F
Uneven running		J	K
Grinding sound, running noise		L	
Radial vibrations	M	N	P
Axial vibrations	O	Q	R

No.	Fault cause	Remedial measures
A	Overload	Reduce load
B	Interruption of a phase in the supply cable / motor winding	Check the converter and supply cables, measure the winding resistances and insulation resistances, repair after consultation with manufacturer
C	Interrupted phase in the feeder cable after switching on	Check the frequency converter, supply cables and the winding resistances
D	Converter output voltage too high, frequency too low	Check the settings on the frequency converter, perform automatic motor identification
F	Winding short-circuit or phase short-circuit in stator winding	Measure the winding resistances and insulation resistances, repair after consultation with the manufacturer, if required, replace the motor
I	Heat dissipation impeded by deposits	Clean the surface of the drives and ensure that the cooling air can flow in and out unimpeded
K	Cooling air inlet/outlet is blocked by foreign bodies	Remove the reason for the blocking and ensure that the cooling air can flow in and out unimpeded
J	Insufficient shielding for motor and/ or encoder cable	Check the shielding and grounding
K	Excessive drive controller gain	Adjust the controller
L	Rotating parts are grinding	Determine cause and adjust parts
M	Foreign bodies inside the motor	Replace the motor
N	Bearing damage	Replace the motor
O	Rotor not balanced	Replace the motor
P	Rotor out of true, shaft bent	Consult the manufacturer
Q	Poor alignment	Align motor set, check coupling
R	Coupled machine not balanced	Re-balance coupled machine
Q	Shocks from coupled machine	Check coupled machine
R	Fault originating from the gearbox	Adjust/repair gearbox

SIMATIC S210 Operating Instructions
www.siemens.com/sinamics-s210



Siemens AG
Digital Factory
Motion Control
Postfach 3180
91050 ERLANGEN
Germany

Edition: 12/2017

